

Eclipse Order Data Import File Structure

Order Data Import Database Structure - Most order data is passed into Eclipse via this specification. This structure supports the core requirements to produce finished parts from a Machine. Other high-level order data might need to be passed via the Bundle Data Import Database for printing or display purposes. Specific punching requirements might need to be passed via the Part Data Import Database. From top to bottom, the fields starting with Bundle are specific to each cutlist item record. That is, each field can be applied to each specific cutlist item in the order, separately. That means, for instance, that even though 2 cutlist items might share the same Bundle Number (for the purpose of packaging those physical parts together after they're produced), they could potentially have different information printed on each item.

Copies of all import data can be saved to the Windows Temp directory if the option is selected in Eclipse\Maintenance\Settings\Import/Export. File names will begin with "D" followed by 7 digit numbers. Order data will be saved in a text file with a .ORD extension.

Field ID	Required	Data Type	Maximum Field Size	Description	Notes	Options
Sqlstatus	Required	char(1)	1*	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Order data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field to "P". When Eclipse has finished processing the data, it will change the field's value to "C". Do NOT change SQL data with a status of "N" or "P" .	
Action_	Required	char(1)	1*	Action Code - Specifies what Eclipse is to do with the associated record fields, such as: 1.) adding a new Order or making changes to an existing Order, 2.) sequencing Orders as they are added, 3.) recalling an Order from the Machine, deleting it from Eclipse and then sending a "returned" notification to the upstream system.	*This field may only contain: C, K, Q, or R	C = Add new Order record or change existing Order record K = Kills an entire order by sending only the Order Number, Material Code, Product Code and the "K" Action Code in a single record Q = Sequence Order and Assign it to a Machine (the Machine Number must be specified in the Machine Number field when this Action Code is used) R = Recall the Order from the Machine controller, delete the Order from Eclipse, and send a "returned" notification to the upstream system
Order_	Required	varchar(20)	20*	Order Number - Identifies a batch of production for a given customer. This number may be duplicated only if the combination of Order Number/Material Code/Product Code form a unique combination.	*XL100 Series controllers are limited to 15 characters	
Material	Required	varchar(20)	20*	Material Code - Defines the type of Material to be used to produce the final product. Material parameters used to generate specific codes are typically: coil width, gauge, color, coating, galvanization, KSI, etc.	*XL100 Series controllers are limited to 18 characters	
Pcode	Required	varchar(20)	20*	Product Code - Defines a set of tooling required to create a particular part shape. This might reference the roll former tooling, punching dies, or a cutoff die. This value should only change if Material must be physically removed from the Machine for the change to take effect. That is, if a punch die simply isn't used for a particular part, that would not constitute a Product Code change. However, if the Machine operator must physically remove one punch die and insert another, that fact should require a Product Code change.	*XL100 Series controllers are limited to 5 characters	
Bundle	Required	smallint	3*	Bundle Number - Identifies a set of lengths and quantities that should be packaged together. Multiple lengths may have the same Bundle Number . Eclipse does not "bundle" automatically. Bundle quantities are passed through exactly as they are processed.	*Bundle 0 always indicates Normal Production Scrap and bundle 900+ indicates Scrap, where the last two digits reference a Scrap Code	
Qty	Required	smallint	4	Quantity - Number of parts to produce.		
Length	Required	decimal(10,3)	10,3*	Part Length - Finished Part Length.	*Lengths must be in decimal inch	

Part_num	Optional	varchar(30)	30	Part Number - This field specifies a pre-defined or imported Part Definition in Eclipse. Typically, Part Numbers only specify punch locations. In some cases, Part Length will also be defined within the Part Definition. If the Part Definition includes length, leave the "Length" field blank when importing Order data.		
Option_	Required	char(1)	1*	Part Option - When programming punched parts, the user will typically define the part with reference to the leading edge of the part. Most commonly, the "leading edge" is the end of the part that exits the Machine first. This would be considered a "right-handed" part, regardless of whether the user is standing so Material exits right-to-left in reference to where the operator typically stands. In order to make punch programming flexible and easy, "right-handed" parts can be produced from the Machine with an opposing punch sequence simply by designating the same part number as a "left-handed" part. This would immediately lay out a punch pattern defined from the leading edge as if it were defined from the trailing edge. Optionally, users can specify an "alternating" part. Most often used by auto parts manufacturers, this produces 2 parts for each part programmed. The Machine will produce a right-handed part immediately followed by a left-handed part. Finally, for extremely complex punching patterns, a "mirrored" option exists. This allows users to program only half the part, and then specify that the Machine controller is to automatically "mirror" the punches on the first half of the part to the other half of the part, creating a mirror image of the punches divided down the center of the part.	*This field may only contain: R, L, A, or M	R = Right-handed L = Left-handed A = Alternating M = Mirrored
Item_id	Required	varchar(22)	22	Item ID - This is a unique identifier per Order cutlist item. Used in combination with Action Codes, this identifier allows the user to make edits to an Order within Eclipse without removing the entire Order from the Eclipse system. Also allows tracking of specific cutlist item data throughout the system.		
Sqlseqnce	Required	smallint	4	SQL Sequence - Defines the processing sequence for cutlist items within an Order that enters the database from the upstream system.		
Stagger	Optional	char(1)	1*	Stagger Panel - This field is used to automatically force the Machine controller to alternate between at least 2 different part lengths in the same bundle. This feature allows convenient interleaving of part lengths within a bundle.	*This field may only contain: S or null	S = Stagger Part Length with Adjoining Lengths also Marked for Stagger
						null = No Stagger
Message	Optional	varchar(40)	40	Operator Message - This is a line of text that will show up embedded within the cutlist of the order, just above the cutlist item originally associated with the message. If no Part Length, Quantity, or Part Number are entered, multi-line messages can be created. Be aware that the Operator Message is not linked to the cutlist item originally associated with it, once the Order reaches the Machine controller. That is, if the operator resequences the cutlist at the Machine, the Operator Message does not move with the original cutlist item. It is simply a line of text within the Order cutlist.		
Machine	Optional*	smallint	2	Machine Number - This field corresponds to the Network Unit ID for a given Machine on the Eclipse network. If Eclipse is to auto-sequence Orders for production at a specific machine, or if Eclipse is to automatically download Orders to a specific machine, the Machine number must be known.	*This field is required when using an Action Code of Q or when using the Schedule Date field	
Schedule	Optional	datetime	8*	Schedule Date - Specifies a date and time to automatically send an Order to a Machine. The Machine Number must be specified in the Machine Number field when the Schedule Date field is used.	*Date format must be DD/MM/YY	

User1	Optional	varchar(254)	254	User Field 1 - The user may use this field for any data not already available within Eclipse. This data is linked to the cutlist item in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
User2	Optional	varchar(254)	254	User Field 2 - The user may use this field for any data not already available within Eclipse. This data is linked to the cutlist item in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
User3	Optional	varchar(254)	254	User Field 3 - The user may use this field for any data not already available within Eclipse. This data is linked to the cutlist item in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
User4	Optional	varchar(254)	254	User Field 4 - The user may use this field for any data not already available within Eclipse. This data is linked to the cutlist item in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
User5	Optional	varchar(254)	254	User Field 5 - The user may use this field for any data not already available within Eclipse. This data is linked to the cutlist item in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
Holecount	Optional*	smallint	4	Hole Count - In some rare instances, the XL200 Series controller is only in control of the cutoff on a Machine that has upstream, in-line punching. In these cases, the XL200 is counting holes pre-punched by an off line system. Instead of programming based on length, this controller is programmed based on the number of holes picked up by a sensor. When Order data is to be programmed in this way, Machine must be told how many holes to "look for" before cutting. This field essentially replaces the "Length" field.	*This field is required by customers who use XL Series Machine controllers with the "H" designator in the software model number	
Offset	Optional*	decimal(8,3)	8,3	Offset - Defines the distance (from the leading edge of a hole picked up by a photo-eye) where the Machine controller will fire the cutoff when operating in Hole Count mode.	*This field is required when using the "Holecount" field	
Sqlplant	Required	varchar(3)	3	SQL Plant - If multiple Eclipse licenses must pull Order data from the same SQL database, this field dictates which Orders belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Order processing	
Partlabel	Optional	varchar(12)	12	Part Print Message Name - This field allows the system to automatically change the Part Print Message at a Machine from the default to whatever pre-defined Part Print Message Name the user selects. The Part Print Message must be pre-defined within Eclipse.		
Bndllabel	Optional	varchar(12)	12	Bundle Print Message Name - This field allows the system to automatically change the Bundle Print Message at a Machine from the default to whatever pre-defined Bundle Print Message Name the user selects. The Bundle Print Message must be pre-defined within Eclipse.		
Bndlecode	Optional	varchar(15)	15	Bundle Code - The user may pass a Bundle Code to Eclipse that will be passed back to the ERP when the Bundle is produced at the machine.		
Bndl_msg	Optional	varchar(254)	254	Bundle Print Message - If the user prefers to directly program printer commands and print data, this field should be used. This field overrides any default print messages created within Eclipse, and this data is passed directly to a Bundle Ticket printer integrated directly to the XL Series controller. It is the user's responsibility to learn and understand the command structure of the printer used.		

Prin_msg	Optional	varchar(254)	254	Part Print Message - If the user prefers to directly program printer commands and print data, this field should be used. This field overrides any default print messages created within Eclipse, and this data is passed directly to an Ink Jet printer integrated directly to the XL Series controller. It is the user's responsibility to learn and understand the command structure of the printer used.		
Kit	Deprecated	empty string	0	Kit Name - Kits are generally used by companies that don't have an in-house ERP system, so it's unlikely there is a pressing need to import Kits to Eclipse. The field has been deprecated in this specification, and should be nulled.		
NoMSubs	Deprecated	null	0	No Material Substitutions - This field was improperly applied in this specification.		
SKU	Optional	varchar(50)	50	SKU - SKU is a code that typically contains data pertaining to both the finished part's profile and raw material properties. If the company uses a SKU number for parts, Eclipse will accept SKU and pass it back.		
Profile	Optional	varchar(50)	50	Profile - This field can be used to print on a part or bundle tag.		
Schedule Time	Optional	varchar(8)	8	Time portion of the Schedule Date above. In 24-hour format		
Piece Mark	Optional	varchar(30)	30	Piece Mark - This can be used to print on a part to uniquely identify it after it is produced.		
BundGrp	Optional	varchar(30)	30	Bundle Group - Used by Eclipse Pro to set bundling rules for each order.		

Eclipse Bundle Data Import Database Structure

Eclipse Bundle Data Import File Structure

Bundle Data Import Database Structure - This structure supports the bundle-specific data typically used in printing bundle tickets. Also supported here are some high-level data fields pertaining to the overall order. For example, this structure supports the **Required Date** field, used by the scheduler (Eclipse user) to determine production sequencing for Orders.

The Bundle field is used to identify some fields as pertaining to the entire Order. The Bundle field is also used to identify other fields as pertaining only to specific Bundles. For this reason, it's possible that each Order imported to the system will carry N + 1 Bundle records; where N = Number of Bundles in the Order (each having its own record and potentially its own data that just pertains to that particular Bundle) + 1 additional record to identify the data that pertains to all Bundles in the Order. For this reason, this specification is broken into 2 parts to help with user understanding of how the structure is applied.

Most companies will want to pass their Customer and shipping information through this data table.

Copies of all import data can be saved to the Windows Temp directory if the option is selected in Eclipse\Maintenance\Settings\Import/Export. File names will begin with "D" followed by 7 digit numbers. Bundle data will be saved in a text file with a .BND extension.

Use this portion of the specification for importing data that is specific to a particular Bundle within an Order.							
Field ID	Required	Data Type	Maximum Field Size	Data Pertains to:	Description	Notes	Column1
Sqlstatus	Required	char(1)	1*	Bundle	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Bundle data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field to "P". When Eclipse has finished processing the data, it will change the field's value to "C". Do NOT change SQL data with a status of "N" or "P".	
Sqlplant	Optional*	varchar(3)	3	Bundle	SQL Plant - If multiple Eclipse licenses must pull Bundle data from the same SQL database, this field dictates which Bundles belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Order processing	
Order_	Required	varchar(20)	20*	Bundle	Order Number - Identifies a batch of production for a given customer. This number may be duplicated only if the combination of Order Number/Material Code/Product Code form a unique combination.	*XL100 Series controllers are limited to 15 characters	
Material	Required	varchar(20)	20*	Bundle	Material Code - Defines the type of Material to be used to produce the final product. Material parameters used to generate specific codes are typically: coil width, gauge, color, coating, galvanization, KSI, etc.	*XL100 Series controllers are limited to 18 characters	
Pcode	Required	varchar(20)	20*	Bundle	Product Code - Defines a set of tooling required to create a particular part shape. This might reference the roll former tooling, punching dies, or a cutoff die. This value should only change if Material must be physically removed from the Machine for the change to take effect. That is, if a punch die simply isn't used for a particular part, that would not constitute a Product Code change. However, if the Machine operator must physically remove one punch die and insert another, that fact should require a Product Code change.	*XL100 Series controllers are limited to 5 characters	
Bundle	Required	smallint	3	Bundle	Bundle Number - Identifies a set of lengths and quantities that should be packaged together. Multiple lengths may have the same Bundle Number. Eclipse does not "bundle" automatically. Bundle quantities are passed through exactly as they are processed.		
User1	Optional	varchar(254)	254	Bundle	User Field 1 - The user may use this field for any data not already available within Eclipse. This data is linked to the Bundle in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
User2	Optional	varchar(254)	254	Bundle	User Field 2 - The user may use this field for any data not already available within Eclipse. This data is linked to the Bundle in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
User3	Optional	varchar(254)	254	Bundle	User Field 3 - The user may use this field for any data not already available within Eclipse. This data is linked to the Bundle in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		

Eclipse Bundle Data Import Database Structure

User4	Optional	varchar(254)	254	Bundle	User Field 4 - The user may use this field for any data not already available within Eclipse. This data is linked to the Bundle in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
User5	Optional	varchar(254)	254	Bundle	User Field 5 - The user may use this field for any data not already available within Eclipse. This data is linked to the Bundle in the associated record. Typically, this field is used to pass print data, or to trigger Custom List events.		
Partlabel	Optional	varchar(12)	12	Bundle	Part Print Message Name - This field allows the system to automatically change the Part Print Message at a Machine from the default to whatever pre-defined Part Print Message Name the user selects. The Part Print Message must be pre-defined within Eclipse.		
Bundlelabel	Optional	varchar(12)	12	Bundle	Bundle Print Message Name - This field allows the system to automatically change the Bundle Print Message at a Machine from the default to whatever pre-defined Bundle Print Message Name the user selects. The Bundle Print Message must be pre-defined within Eclipse.		
Bndl_msg	Optional	varchar(254)	254	Bundle	Bundle Print Message - If the user prefers to directly program printer commands and print data, this field should be used. This field overrides any default print messages created within Eclipse, and this data is passed directly to a Bundle Ticket printer integrated directly to the XL Series controller. It is the user's responsibility to learn and understand the command structure of the printer used.		
Prin_msg	Optional	varchar(254)	254	Bundle	Part Print Message - If the user prefers to directly program printer commands and print data, this field should be used. This field overrides any default print messages created within Eclipse, and this data is passed directly to an Ink Jet printer integrated directly to the XL Series controller. It is the user's responsibility to learn and understand the command structure of the printer used.		
Kit	Deprecated	empty string	0	Deprecated	Kit Name - Kits are generally used by companies that don't have an in-house ERP system, so it's unlikely there is a pressing need to import Kits to Eclipse. The field has been deprecated in this specification, and should be nulled.		

Use this portion of the specification for importing data that pertains to the entire Order.

Field ID	Required	Data Type	Maximum Field Size	Data Pertains to:	Description	Notes	Column1
Sqlstatus	Required	char(1)	1*	Order	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Bundle data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field.	
Sqlplant	Optional*	varchar(3)	3	Order	SQL Plant - If multiple Eclipse licenses must pull Bundle data from the same SQL database, this field dictates which Bundles belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Order processing	
Order_	Required	varchar(20)	20*	Order	Order Number - Identifies a batch of production for a given customer. This number may be duplicated only if the combination of Order Number/Material Code/Product Code form a unique combination.	*XL100 Series controllers are limited to 15 characters	
Material	Required	varchar(20)	20*	Order	Material Code - Defines the type of Material to be used to produce the final product. Material parameters used to generate specific codes are typically: coil width, gauge, color, coating, galvanization, KSI, etc.	*XL100 Series controllers are limited to 18 characters	
Pcode	Required	varchar(20)	20*	Order	Product Code - Defines a set of tooling required to create a particular part shape. This might reference the roll former tooling, punching dies, or a cutoff die. This value should only change if Material must be physically removed from the Machine for the change to take effect. That is, if a punch die simply isn't used for a particular part, that would not constitute a Product Code change. However, if the Machine operator must physically remove one punch die and insert another, that fact should require a Product Code change.	*XL100 Series controllers are limited to 5 characters	
Bundle	Required	smallint	1*	Order	Bundle Number - In this portion of the specification, the Bundle Number must be 0. Eclipse will apply all associated record fields to the entire Order.	*Bundle Number must be 0	

Eclipse Bundle Data Import Database Structure

Req_date	Optional	datetime	8	Order	Required Date - The date the Order must be completed.		
Hold	Optional	bit	1*	Order	Hold - If this field is True, then the Order will be imported to Eclipse with a status of Hold. No other functions within the system will allow the Order to go down to the Machine controller until a Scheduler releases the Order (Schedule Orders\Release).	*This field may only contain: True or False	True = Order is imported with status of Hold False = Order is not held on import
User1	Optional	varchar(254)	254	Order	User Field 1 - Use this field for any data not already available within Eclipse. This data is linked to the Order. Typically, this field is used to pass print data, or to trigger Custom List events.		
User2	Optional	varchar(254)	254	Order	User Field 2 - Use this field for any data not already available within Eclipse. This data is linked to the Order. Typically, this field is used to pass print data, or to trigger Custom List events.		
User3	Optional	varchar(254)	254	Order	User Field 3 - Use this field for any data not already available within Eclipse. This data is linked to the Order. Typically, this field is used to pass print data, or to trigger Custom List events.		
User4	Optional	varchar(254)	254	Order	User Field 4 - Use this field for any data not already available within Eclipse. This data is linked to the Order. Typically, this field is used to pass print data, or to trigger Custom List events.		
User5	Optional	varchar(254)	254	Order	User Field 5 - Use this field for any data not already available within Eclipse. This data is linked to the Order. Typically, this field is used to pass print data, or to trigger Custom List events.		
Partlabel	Optional	varchar(12)	12	Order	Part Print Message Name - This field allows the system to automatically change the Part Print Message at a Machine from the default to whatever pre-defined Part Print Message Name the user selects. The Part Print Message must be pre-defined within Eclipse.		
Bundlelabel	Optional	varchar(12)	12	Order	Bundle Print Message Name - This field allows the system to automatically change the Bundle Print Message at a Machine from the default to whatever pre-defined Bundle Print Message Name the user selects. The Bundle Print Message must be pre-defined within Eclipse.		
Bndl_msg	Optional	varchar(254)	254	Order	Bundle Print Message - If the user prefers to directly program printer commands and print data, this field should be used. This field overrides any default print messages created within Eclipse, and this data is passed directly to a Bundle Ticket printer integrated directly to the XL Series controller. It is the user's responsibility to learn and understand the command structure of the printer used.		
Prin_msg	Optional	varchar(254)	254	Order	Part Print Message - If the user prefers to directly program printer commands and print data, this field should be used. This field overrides any default print messages created within Eclipse, and this data is passed directly to an Ink Jet printer integrated directly to the XL Series controller. It is the user's responsibility to learn and understand the command structure of the printer used.		
Custname	Optional	varchar(30)	30	Order	Customer Name - Customer Name where the finished parts will be shipped.		
Custaddr1	Optional	varchar(254)	254	Order	Customer Street or "Shipping" Address - First Line - The first line for the customer's street or shipping address.		
Custaddr2	Optional	varchar(254)	254	Order	Customer Street or "Shipping" Address - Second Line - The Second line for the customer's street or shipping address.		
Custcity	Optional	varchar(254)	254	Order	Customer City - City where the Customer is located.		
Custstate	Optional	varchar(2)	2	Order	Customer State - State where the Customer is located.		
Custzip	Optional	varchar(10)	10	Order	Customer Zip Code - Customer postal code.		
Custcntry	Optional	varchar(3)	3	Order	Customer Country - Country code where the Customer is located.		
Custinstr	Optional	varchar(254)	254	Order	Customer Shipping Instructions - Typically, these would be standard instructions for shipping to this particular customer. If there are special instructions for shipping a specific Order, those should be handled in a different field in a different table (ie - a user field in the Bundle Table).		
Stagebay	Optional	varchar(10)	10	Order	Staging Bay - The bay where finished parts should be staged.		
Loaddock	Optional	varchar(10)	10	Order	Loading Dock - The specific Loading Dock where the finished parts should be loaded onto a shipping vessel.		
Workorder	Optional	varchar(18)	18	Order	Work Order - The Work Order number associated with this batch of production.		
Trucknbr	Optional	varchar(12)	12	Order	Truck Number - The Truck Number on which the finished Order should be loaded.		

Eclipse Bundle Data Import Database Structure

Pcodegrp	Optional	varchar(15)	15	Order	Product Code Group - The Product Group to which this Product is assigned.		
Hold	Optional	Logical	1*	Order	Hold - If this field is True, then the Order will be imported to Eclipse with a status of Hold. No other functions within the system will allow the Order to go down to the Machine controller until a Scheduler releases the Order (Schedule Orders\Release).	*This field may only contain: T or F	T = Order is imported with status of Hold F = Order is not held on import
Required Time	Optional	varchar(8)	8	Order	Time component of req_time field above. In 24-hour format.		
CustPhone	Optional	varchar(20)	20	Order			
CustPO	Optional	varchar(30)	30	Order			
SalesOrder	Optional	varchar(30)	30	Order			
ShipDate	Optional	datetime		Order			
CustNum	Optional	varchar(30)	30	Order			
MaxBundLbs	Optional	int	8	Order	Used by Eclipse Pro to set bundling rules for each order.		
MaxBundQty	Optional	int	8	Order	Used by Eclipse Pro to set bundling rules for each order.		

Eclipse Part Data Import Database Structure

Eclipse Part Data Import File Structure

Part Data Import Database Structure - Punch patterns and ink jet printing locations can be imported using this specification. Ink jet printers are treated as if they were punch presses in terms of Tool Definitions and References.

Copies of all import data can be saved to the Windows Temp directory if the option is selected in Eclipse\Maintenance\Settings\Import/Export. File names will begin with "D" followed by 7 digit numbers. Order data will be saved in a text file with a .PRT extension.

Field ID	Required	Data Type	Maximum Field Size	Description	Notes	Column1
SqlStatus	Required	char(1)	1*	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Order data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field to "P". When Eclipse has finished processing the data, it will change the field's value to "C". Do NOT change SQL data with a status of "N" or "P".	
Part_num	Required	varchar(30)	30	Part Number - Defines the specific Part Number that will be referenced any time this particular punch pattern is desired on a finished part. Typically, Part Numbers only specify punch locations. In some cases, Part Length will also be defined within the Part Definition. If the Part Definition includes length, null the "Length" field in the Order data import database.		
Tool	Required*	smallint	3	Tool Number - Defines the specific Tool Number to be used on the Machine to achieve the punch target(s). The Machine controller that will make the finished part must have a Tool Number corresponding to a physical tool defined in its Tool Data menu.	*If entering a Macro reference, this field should be null	
Reference	Required	tinyint	1*	Reference - Defines the feature on the part from which the punch location will be referenced in the X direction. Reference options include: Leading Edge, Trailing Edge, Leading Center, Trailing Center, Even Spacing, Spacing Limit and Kerf Adjust.	*This field may only contain: 0, 1, 2, 3, 4, 5, or 8	0 = Leading Edge 1 = Trailing Edge 2 = Leading Center 3 = Trailing Center 4 = Even Space 5 = Spacing Limit 8 = Kerf Adjust
Offset	Required	decimal(10,3)	10,3	X-Offset - Defines the distance from the reference point where the tooling must strike the Material to achieve the correct target location in the X-axis.		
Permanent_	Required	char(1)	1*	Permanent - Defines whether Eclipse should keep the part in the Parts Definition database permanently, or if it should be automatically deleted when there is no longer an Order in the system that calls for that Part Definition.	*This field may only contain: T or F	T = True F = False
Y_Ref	Optional*	tinyint	1**	Y-Reference - Defines the feature on the part or Machine from which the punch location will be referenced in the Y direction. Reference options include: Center +, Center -, Edge +, Edge -, Macro +, and Macro -.	*This field is required if importing Part Definitions that include Y-axis punch targets **This field may only contain: 1, 2, 3, 4, 5, or 6	1 = Center + 2 = Center - 3 = Edge + 4 = Edge - 5 = Macro + 6 = Macro -
Y_Offset	Optional*	decimal(8,3)	8,3**	Y-Offset - Defines the distance from the Y-Reference point where the tooling must move to achieve the correct target location in the Y-axis.	*This field is required if importing Part Definitions that include Y-axis punch targets **Lengths must be in decimal inch	
Macro	Optional	varchar(30)	30	Macro Name - Specifies a reference to a pre-defined macro definition within Eclipse. Macros cannot be imported into Eclipse, but must be entered manually into the Parts\Part Definition form.		

Eclipse Part Data Import Database Structure

Length	Optional*	decimal(10,3)	10,3**	Part Length - Finished Part Length. This field should only be used when the punch pattern for a given part is specific to a particular length. If the length and punch pattern are not directly related, null this field, and use the "Length" field in the Order data import database.	*The "Length" field is required if Part Length is not included in the Order Data Import Database **Lengths must be in decimal inch
Sqlplant	Optional*	varchar(3)	3	SQL Plant - If multiple Eclipse licenses must pull Part data from the same SQL database, this field dictates which Parts belong to which plant's license.	*Required any time multiple licenses will use the same SQL database for Order processing
Option_	Deprecated	empty string	0	Part Option - The Part Option field in the Order Data Import Database always supercedes the value in the Part data transfer. The field has been deprecated in this specification, and should be nulled.	

Eclipse Coil Data Import Database Structure

Coil Data Import Database Structure - Coil Inventory data is passed into Eclipse via this specification.

It is important to note, Eclipse can validate Coils - When a Machine operator loads a coil onto a Machine, the system can check to make sure the Coil's Material type matches the requirements for the Order to be produced. The user has a choice between pushing this data into a database for Eclipse to use, or using an existing SQL database within his own system.

When Coil validation occurs with an external database, the potential exists for some reporting structures to have inaccurate/missing data. Specifically, costing (reports showing the cost of an order based on raw Material consumption, as well as scrap costs) and footage used when there are processes that consume Material on Machines outside of the Eclipse network.

If Eclipse's reports aren't used, these issues don't matter. If accurate Eclipse reports are important to the user, then the Coil Database Structure in Eclipse should be maintained. Any Materials consumed by an external process should update the Eclipse Coil Database.

External Coil validation is covered at the end of this specification.

Copies of all import data can be saved to the Windows Temp directory if the option is selected in Eclipse\Maintenance\Settings\Import/Export. File names will begin with "D" followed by 7 digit numbers. Coil data will be saved in a text file with a .COI extension.

Field ID	Required	Data Type	Maximum Field Size	Description	Notes	Column1
Sqlstatus	Required	char(1)	1*	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Order data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field to "P". When Eclipse has finished processing the data, it will change the field's value to "C". Do NOT change SQL data with a status of "N" or "P".	
Sqlplant	Optional*	varchar(3)	3	SQL Plant - If multiple Eclipse licenses must pull Coil data from the same SQL database, this field dictates which Coils belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Coil processing.	
Action_	Required	char(1)	1*	Action Code - Specifies what Eclipse is to do with the associated record fields, such as: 1.) adding a new Coil, 2.) making changes to an existing Order, 3.) deleting a Coil from Eclipse.	*This field may only contain: A, C, or D	A = Add new Coil record C = Change information regarding an existing Coil. Unchanged fields should remain empty D = Delete the Coil from Eclipse
Invcoil	Required	varchar(16)	30*	Inventory Coil Number - Identifies a specific Coil within the inventory.	* 16 for XL firmware before Sept, 2016	
Material	Required	varchar(20)	20*	Material Code - Defines the type of Material to be used to produce the final product. Material parameters used to generate specific codes are typically: coil width, gauge, color, coating, galvanization, KSI, etc.	*XL100 Series controllers are limited to 18 characters	
Desc	Optional	varchar(40)	40	Description - Description of the Material type.		
Heatnbr	Optional	varchar(20)	20	Heat Number - Heat Number.		
Status	Optional	char(1)	1*	Status - Defines whether the Coil has been completely consumed, or if it is incomplete.	*This field may only contain: I or C	I = Incomplete C = Complete
Vendcode	Optional	varchar(16)	16	Vendor Code - Internal company code used to reference the Vendor Name.		
Purchord	Optional	varchar(10)	10	Purchase Order Number - The Purchase Order Number used to buy this Coil.		
Datein	Optional	varchar(10)	10	Date In - The date the Coil was added to the inventory.		
Dateout	Optional	varchar(10)	10	Date Out - The date the Coil was removed from inventory (completely consumed by production, or shipped to another location).		
L_start	Optional	varchar(8)	8*	Starting Length - Beginning length of Coil.	*Length must be in feet	
L_used	Optional	varchar(8)	8*	Length Used - Any length already consumed.	*Length must be in feet	
Weight	Optional	varchar(10)	10*	Weight - The starting Weight of the coil in pounds.	*Weight must be in pounds	
Type	Optional	varchar(10)	10	Type of Coil - Used to categorize the Coil within the user's own terminology.		
Cost_lb	Optional	varchar(7)	7	Cost Per Pound - Defines the cost of the Coil Material per lb.		

Eclipse Coil Data Import Database Structure

Nex_scrap	Optional	varchar(9)	9	Non-Exempt Scrap - When importing Coil data where Coils might be consumed by other processes (any situation where a Coil could be used where Eclipse can't track the usage), this field is used to pass Scrap tracking information back into Eclipse from the outside processes. Non-Exempt Scrap is Scrap that detracts from the operator's performance (Scrap footage over which the Machine operator has control).		
Ex_scrap	Optional*	varchar(9)	9	Exempt Scrap - When importing Coil data where Coils might be consumed by other processes (any situation where a Coil could be used where Eclipse can't track the usage), this field is used to pass Scrap tracking information back into Eclipse from the outside processes. Exempt Scrap is tallied for total Scrap tracking, but does not count against the Machine operator's performance (raw Material scrap, or scrap due to Material handling).		
Oth_adjst	Optional	varchar(9)	9	Other Adjust - This field allows users to reconcile Coil consumption from processes external to the Eclipse system.		
Storloc	Optional	varchar(20)	20	Storage Location - The physical location where this Coil is stored.		

Verifying Coils Against an Existing Database

Below are the fields required to allow Eclipse to validate Coils against an existing SQL database.

Field Name	Required	Data Type	Maximum Field Size	Description	Column1	Column2
INVCOIL	Required	varchar(16)	16	Inventory Coil Number - Identifies a specific Coil within the inventory.		
MATERIAL	Required	varchar(20)	20*	Material Code - Defines the type of Material to be used to produce the final product. Material parameters used to generate specific codes are typically: coil width, gauge, color, coating, galvanization, KSI, etc.	*XL100 Series controllers are limited to 18 characters	
REMAINING	Optional	varchar(8)	8*	Remaining Length - Feet remaining on the Coil.	*Length must be in feet	
STATUS	Optional	char(1)	1*	Status - Defines whether the Coil has been completely consumed, or if it is incomplete.	*This field may only contain: I or C	I = Incomplete C = Complete
LB_FT	Optional	decimal(7,3)	8,3	Pounds per Foot - Weight of Coil Material per linear foot.		

Eclipse Material Data Import Database Structure

Eclipse Material Data Import File Structure

Material Data Import Database Structure - This data is added to a Material Definitions Table within Eclipse. Eclipse must at least have the Material Code before an Order can be processed.

Predicting Bundle weights before the Bundles have been produced requires information from this internal table. Several fields are primarily used for printing purposes, but can be displayed throughout the system for the schedulers' and Machine operators' benefit.

Typically, this table is imported once, and then only used to alert Eclipse to changes regarding existing Material definitions, or when deleting or adding records.

Copies of all import data can be saved to the Windows Temp directory if the option is selected in Eclipse\Maintenance\Settings\Import/Export. File names will begin with "D" followed by 7 digit numbers. Material data will be saved in a text file with a .MAT extension.

Field ID	Required	Data Type	Maximum Field Size	Description	Notes	Column1
Sqlstatus	Required	char(1)	1*	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Customer data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field to "P". When Eclipse has finished processing the data, it will change the field's value to "C". Do NOT change SQL data with a status of "N" or "P".	
Action_	Required	char(1)	1*	Action Code - Specifies what Eclipse is to do with the associated record fields, such as: 1.) adding a new Material definition, 2.) making changes to an existing Material definition (leave unchanged fields null), 3.) deleting a Material definition from the database.	*This field may only contain: A, C, or D	A = Add new Material definition record C = Change Material definition record (leave unchanged fields null) D = Delete Material definition record
Material	Required	varchar(20)	20*	Material Code - Identifies a specific raw Material type based on the user's parameters - typically coil width, thickness, color, coating, etc.	*XL100 Series controllers are limited to 18 characters	
Descript	Optional	varchar(40)	40	Material Description - This is the "human readable" identification or Description of the Material Code.		
Gauge	Optional	tinyint	2	Material Gauge - Standard Gauge value for Material type.		
Thickness	Optional	decimal(6,4)	6,4*	Material Thickness - The physical thickness of the Material in decimal inches.	*Thickness must be in decimal inch	
Width	Optional	decimal(6,4)	6,4*	Material Width - Starting width of Material in decimal inches. Coil width.	*Width must be in decimal inch	
Color	Optional	varchar(20)	20	Material Color - Color of Material if using painted product.		
Type	Optional	varchar(10)	10	Material Type - Type of Material.		
Lb_ft	Optional	decimal(7,3)	7,3*	Pounds Per Foot - The weight of the Material in Pounds Per Foot. This value is used to calculate and pre-estimate the weight of bundles before they are produced. The Scheduler can see the estimate before sending Orders to the Machines.	*Weight must be in pounds	
Cost_lb	Optional	decimal(7,2)	7,2	Cost Per Pound - Defines the average cost of this Material type per pound. If cost information is not defined for a Coil, Eclipse will attempt to calculate raw Material costs based on the Material definition, instead.		
Reorder	Optional	tinyint	6	Reorder Point - This is the amount of Material remaining on-hand that should prompt the Purchasing Agent should buy more of this Material type.		
Sqlplant	Optional*	varchar(3)	3	SQL Plant - If multiple Eclipse licenses must pull Customer data from the same SQL database, this field dictates which Customers belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Order processing	
Cover	Deprecated	null	0	Coverage Area - Originally, this parameter defined the finished width of a panel. Since that parameter is now part of the Product Code field, this field has been deprecated.		

Eclipse Material Data Import Database Structure

Normlngth	Deprecated	null	0	Normal Length - Before full Coil support was in Eclipse, this value was used to import the "Normal Length of a Coil of this Material Type". This field is no longer necessary and has been deprecated.		
-----------	------------	------	---	---	--	--

Eclipse Product Data Import Database Structure

Eclipse Product Data Import File Structure

Product Data Import Database Structure - This data is added to a Product Definitions Table within Eclipse.

IMPORTANT NOTE

Throughout the Eclipse system, the word PRODUCT always references a particular finished part profile - ie. shape. The only parameter for Product is the finished part profile. In other words, the Product Code should only change between Orders when there is a difference in Machine tooling required to produce the new shape. In terms of the Eclipse system, a tooling difference always means Material must be cleared from the Machine before the new tooling can be put into place to make the new profile.

Product Codes must not carry parameters such as: raw Material type, length, or any punching information (unless the punching requires a physical tooling change on the Machine that requires the Material to be cleared from the Machine before the tooling can be mounted).

Typcially, this table is imported once, and then only used to alert Eclipse to changes regarding existing Product definitions, or when deleting or adding records.

Copies of all import data can be saved to the Windows Temp directory if the option is selected in Eclipse\Maintenance\Settings\Import/Export. File names will begin with "D" followed by 7 digit numbers. Material data will be saved in a text file with a .PCD extension.

Field ID	Required	Data Type	Maximum Field Size	Description	Notes	Column1
Sqlstatus	Required	char(1)	1*	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Customer data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field to "P". When Eclipse has finished processing the data, it will change the field's value to "C". Do NOT change SQL data with a status of "N" or "P".	
Sqlplant	Optional*	varchar(3)	3	SQL Plant - If multiple Eclipse licenses must pull Product data from the same SQL database, this field dictates which Customers belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Product Code processing	
Action_	Required	char(1)	1*	Action Code - Specifies what Eclipse is to do with the associated record fields, such as: 1.) adding a new Product definition, 2.) making changes to an existing Product definition (leave unchanged fields nulled), 3.) deleting a Product definition from the database.	*This field may only contain: A, C, or D	A = Add new Product definition record C = Change Product definition record (leave unchanged fields nulled) D = Delete Product definition record
Pcode	Required	varchar(20)	20*	Product Code - Identifies the finished Product shape, or tooling required to produce a given Product shape.	*XL100 Series controllers are limited to 5 characters	
Machine	Required	smallint	3	Machine Number - This is the Network Unit ID for the Machine that can produce this Product. For each Machine that is capable of running a given Product, there must be another definition for that Product Code in the Product Code Definitions table in Eclipse. Orders with a Product Code cannot be sent to a Machine unless there is a corresponding Product Code definition tying the Machine to the Product Code.		
Desc_	Optional	varchar(30)	30	Product Description - This is the "human readable" identification or Description of the Product Code.		
Finwidth	Optional	decimal(8,3)	8,3*	Finished Width - Defines the width of the finished Product after the forming process is complete.	*Width must be in decimal inch	
Legheight	Optional	decimal(8,3)	8,3*	Leg Height - Defines the longest "leg" or vertical section of the finished Product shape.		
Pcodegrp	Optional	varchar(20)	20	Product Code Group - Allows the user to assign multiple Product Codes to a Product Group or "family of products".		

Eclipse Product Data Import Database Structure

Coilchgmin	Optional*	decimal(6,3)	6,3	Average Minutes Per Coil Change - This is the average time required to complete a Coil change for this particular Product. This value is used when Eclipse estimates completion times.	*This field is required if the user is to rely on the estimated Order completion times in Eclipse. The more Coil changes per shift that take place, the farther the completion times are skewed without this data.	
Toolchgmin	Optional*	decimal(6,3)	6,3	Average Minutes Per Tooling Change - This is the average time required to complete a Tooling change for this particular Product. This value is used when Eclipse estimates completion times.	*This field is required if the user is to rely on the estimated Order completion times in Eclipse. The more Coil changes per shift that take place, the farther the completion times are skewed without this data.	
Ft_minutes	Optional*	smallint	4**	Maximum Line Speed in Feet Per Minute - Defines the maximum line speed for this Product. This value is used when calculating OEE values in Eclipse. For more accurate OEE numbers relating to Machine speed, the user must interface with Eclipse to define maximum speed based on part length.	*This field is required if the user will rely on OEE reports from Eclipse **Line speed must be in feet per minute	
Stagebay	Optional	varchar(10)	10	Staging Bay - Defines the default Staging Bay for this Product. If the Staging Bay field in the Bundle Data Import structure is used, that value overrides this value for a specific Order.		
Loaddock	Optional	varchar(10)	10	Loading Dock - Defines the default Staging Bay for this Product. If the Staging Bay field in the Bundle Data Import structure is used, that value overrides this value for a specific Order.		
Holecount	Optional*	bit	1**	Hole Count - In some rare instances, the XL200 Series controller is only in control of the cutoff on a Machine that has upstream, in-line punching. In these cases, the XL200 is counting holes pre-punched by an off line system. Instead of programming based on length, this controller is programmed based on the number of holes picked up by a sensor. When Order data is to be programmed in this way, the Product Code must specify Hole Counting.	*This field is required when sending Order data to a XL200 Series controller with the Hole Count model option, when the machine is in the Hole Count mode **This field may only contain: True or False	True = Orders containing this Product Code will cut parts to length based on hole count, not length in inches False = Orders containing this Product Code will cut parts to length based on length in inches, not hole count
Calclength	Optional*	bit	1**	Calculate Length - In order for a XL200 Series controller to report production data back to Eclipse, part lengths must be present in the order data sent to the Machine. If the user will not import the length data in the Length fields from other Data Import structures, Eclipse must calculate the length based on the number of holes to count and the distance between each hole.	*This field is required when sending Order data to a XL200 Series controller when the length will not be sent in the Order Data structure **This field may only contain: True or False	True = Eclipse will calculate estimated part length based on number of holes multiplied by the Hole Spacing field False = Eclipse will not send length-based data to the XL200 series controller
Holespace	Optional*	decimal(8,3)	8,3**	Hole Spacing - Defines the physical distance between holes on pre-punched parts when counting holes for length control.	*This field is required when sending Order data to a XL200 Series controller when the length will not be sent in the Order Data structure **Length must be in decimal inch	

Eclipse Customer Data Import Database Structure

Eclipse Customer Data Import File Structure

Customer Data Import Database Structure - This data is added to a Customer table within Eclipse that can be automatically recalled by associating the customer code to an Order in the Bundle Table.

This information is most often used to print Bundle Tickets for shipping purposes. It's also used in Eclipse production history reports as a filterable field, and can be displayed in other areas of the system (the machine controller, for instance) for whatever purpose the user desires.

If importing data from a ERP system, the most efficient way to handle passing Customer shipping information is to always pass the Customer fields in the Bundle Data Table.

Copies of all import data can be saved to the Windows Temp directory if the option is selected in Eclipse\Maintenance\Settings\Import/Export. File names will begin with "D" followed by 7 digit numbers. Customer data will be saved in a text file with a .CUS extension.

Field ID	Required	Data Type	Maximum Field Size	Description	Notes	Column1
Sqlstatus	Required	char(1)	1*	SQL Status - Alerts Eclipse when new data is available for processing, and alerts the upstream system when Eclipse has processed Customer data.	*When the upstream system enters data into the SQL database, this field should have a value of "N". While Eclipse is processing the data, Eclipse will change the status of the field to "P". When Eclipse has finished processing the data, it will change the field's value to "C". Do NOT change SQL data with a status of "N" or "P".	
Action_	Required	char(1)	1*	Action Code - Specifies what Eclipse is to do with the associated record fields, such as: 1.) adding a new Customer, 2.) making changes to an existing Customer (leave unchanged fields nulled), 3.) deleting a Customer from the database.	*This field may only contain: A, C, or D	A = Add new Customer record C = Change Customer record (leave unchanged fields nulled) D = Delete Customer record
Custcode	Required	varchar(11)	11	Customer Code - Identifies a customer by internally generated and		
Name	Required	varchar(30)	30	Customer Name - Company name of customer.		
Address1	Optional	varchar(30)	30	Customer Street or "Shipping" Address - First Line - The first line for the customer's street or shipping address.		
Address2	Optional	varchar(30)	30	Customer Street or "Shipping" Address - Second Line - The Second line for the customer's street or shipping address.		
City	Optional	varchar(30)	30	Customer City - City where the Customer is located.		
State	Optional	varchar(2)	2	Customer State - State where the Customer is located.		
Zip	Optional	varchar(10)	10	Customer Zip Code - Customer postal code.		
Country	Optional	varchar(3)	3	Customer Country - Country code where the Customer is located.		
Shipinstru	Optional	varchar(30)	30	Customer Shipping Instructions - Typically, these would be standard instructions for shipping to this particular customer. If there are special instructions for shipping a specific Order, those should be handled in a different field in a different table (ie - a user field in the Bundle Table).		
Maxbndlwt	Optional	smallint	4	Maximum Bundle Weight - Defines maximum weight per bundle the Customer can handle from a truck (due to crane or fork lift restrictions).		
Delphone	Optional	varchar(30)	30	Delivery Phone Number - The contact phone number at the point of delivery.		
Emailaddr	Optional	varchar(100)	100	E-mail Address - The contact e-mail address at the point of delivery.		
Sqlplant	Optional*	varchar(3)	3	SQL Plant - If multiple Eclipse licenses must pull Customer data from the same SQL database, this field dictates which Customers belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Order processing	

Eclipse Production Data Export Database Structure

Eclipse Production Data Import File Structure

Production Data Export Database Structure - All Production data from the Machine(s) is pulled into Eclipse, and is available for export to an upstream system. The Production data from Eclipse is exactly the same data and format that comes from the Machine(s), as it comes from the Machine(s). Production data is reported to Eclipse in a "stream of consciousness" fashion, that is, each event updates Eclipse with all current order status at the same time the event that triggered the event is reported. For instance, if the Machine Operator halts the line, an event record is created to report "Machine Operator halted the line". At the same time, had the operator recently run 5 pieces of a 50 piece bundle, the report would also include that 5 pieces were completed on the current bundle. Eclipse tracks all of this and uses this information for completions. There is no final "Bundle was completed" report from the Machine.

Field ID	Data Type	Maximum Field Size	Description	Notes	Column1
Sqlstatus	char(1)	1*	SQL Status - When Eclipse enters a new record into the Production Data Export table to be processed by the upstream system, this field will contain "N" for New Record.	*This field will only contain: N	N = New Record
Sqlplant	varchar(3)	3	SQL Plant - If multiple Eclipse licenses will push Production data to the same SQL database, this field dictates which Production records belong to each plant's license.	*Required any time multiple licenses will use the same SQL database for Order processing	
Plantname	varchar(30)	30	Plant Name - The name of the plant pushing Production record data to a central SQL database.		
Type	char(1)	1*	Production Record Type - Defines the Type of Production record reported.	*This field will only contain: 1, 2, 3, 4, 5, 6, 7, 8, C, S, E, or G	1 = General Production record 2 = Production record related to Coil change 3 = Machine Operator placed XL Series controller into Run mode 4 = Machine Operator powered up XL Series controller 5 = Order requested by Machine Operator from XL Series controller 6 = XL Series controller reports an on-screen message (warning, error, notification) 7 = Machine Operator reported a Downtime code 8 = Custom List request or Query List feedback from Machine Operator C = Query List was triggered at XL Series controller S = Start of Shift E = End of Shift G = General feedback record
Reason	varchar(3)	3*	Production Record Type Reason - Defines the Reason for the original Record Type. Each Reason Code is defined by its parent Record Type.	*For Record Type 1 this field will only contain: B, C, E, H, I, M, O, P, R, T, X, Y, or Z	B = Machine halted automatically due to a Bundle number change. The XL Series controller must be in Bundle Halt Mode C = Coil Tailout sensor detects passage of end of Coil. Machine is automatically halted and End of Coil Scrap Code is reported for any remaining Material, unless Machine Operator running a Scrap Bundle with 900+ Bundle Number, in which case that Scrap reason is reported for remaining material

Eclipse Production Data Export Database Structure

					E = Machine was automatically halted because the programmed Coil Endpoint was reached. Machine Operator was prompted to cut the Coil at the pre-determined point prior to the entry to the roll former
					H = Machine Operator halted the Machine manually
					I = XL Series controller reports Bundle completion, but Machine controller was not configured for Bundle Halt Mode, so Machine continues producing by immediately and automatically changing to next Bundle
					M = XL Series controller reports Manual Shear by Machine Operator
					O = XL Series controller halts Machine automatically due to Out-of-Orders. There were no more Orders to run that could be queued (Material Code or Product Code change, or simply no more Orders in memory)
					P = Machine Operator removed power from the XL Series controller
					R = Machine Operator employed Remake function on Machine controller to replace Scrap parts
					T = XL Series controller automatically halted Machine due to Out of Tolerance part
					X = Machine Operator employed Decrease Quantity function to alert the system that a part previously counted as Scrap is actually Good Footage
					Y = Machine Operator employed Increase Quantity on Machine controller to replace scrap parts
					Z = Machine coast-to-stop. This code will always accompany a 1C record for a Tailout situation
				*For Record Type 2 this field will only contain: D, L or R	D = Machine Operator reported Coil was completely consumed
					L = Machine Operator reported new Coil loaded
					R = Machine Operator reported remaining Coil was returned to inventory
				*For Record Type 8 this field will only contain: C or Q	C = Custom List feedback from Machine Operator
					Q = Quality Audit feedback from Machine Operator
				*For Record Type E and S this field will only contain: H or R	H = Runtime record
					R = Downtime record
				*For Record Type G this field will only contain: C, D, I, M, R, S, U, or X	C = Coil inventory update
					D = Order is Done

Eclipse Production Data Export Database Structure

					I = Order added to Eclipse via import
					M = Order sent to XL Series controller
					R = Order returned to ERP system
					S = Order started at machine
					U = Order Recalled from controller to Eclipse
					X = Order deleted from Eclipse via import
Date_	datetime	8	Date - The date the Production record was created at the XL Series controller.		
Time_	varchar(8)	8*	Time - The time the Production record was created at the XL Series controller.	*Time format is HH:MM:SS in 24 hour format	
ProdDate	datetime	8	Production Date - The shift date. If a shift crosses midnight, this date indicates the shift started the day before.		
Shift	tinyint	1*	Shift Number - First, second or third shift.	*This field will only contain: 1, 2, or 3	1 = First shift 2 = Second shift 3 = Third shift
Machine	smallint	3	Machine Number - Same as the Network Unit ID for each XL Series controller. Each XL Series controller must have its own unique Network Unit ID.		
Employ_id	int	7	Employee ID - Employee number used to identify the Machine Operator or employee currently responsible for the Machine. If no Employee ID is entered at the Machine, a default of "0" is used.		
Name	varchar(30)	30	Employee Name - Employee Name used to identify the Machine Operator or employee currently responsible for the Machine. If no Employee Name is entered at the Machine, a default of "0" is used.		
Order_	varchar(20)	20	Order Number - Order Number ran at the Machine. This number will reflect Orders sent from Eclipse or entered by hand by the Machine Operator.		
Material	varchar(20)	20	Material Code - Defines the type of Material to be used to produce the final product. This number will reflect Orders sent from Eclipse or entered by hand by the Machine Operator.		
Pcode	varchar(20)	20	Product Code - Defines a set of tooling required to create a particular part shape. This number will reflect Orders sent from Eclipse or entered by hand by the Machine Operator.		
Bundle	smallint	3*	Bundle Number - Identifies a set of lengths and quantities that should be packaged together. Multiple lengths may have the same Bundle Number. This number will reflect the Orders sent from Eclipse or entered by hand by the Machine Operator.	*Bundle 0 always indicates Normal Production Scrap and bundle 900+ indicates Scrap, where the last two digits reference a Scrap Code	
Qty	smallint	4	Quantity - Number of parts to produced since the last Production record.		
Length	decimal(10,3)	10,3*	Part Length - Finished Part Length . This is the length actually produced, regardless of whether the Order was sent from Eclipse or entered by hand by the Machine Operator.	*Lengths will be in decimal inch	
Item_id	varchar(22)	22	Item ID - This is a unique identifier per Order cutlist item. It allows tracking of specific cutlist item data throughout the system.		
Option_	char(1)	1*	Part Option - Indicates the Part Option used for producing punched parts at the Machine.	*This field will only contain: R, L, A, M, or H	R = Right-handed L = Left-handed A = Alternating M = Mirrored H = Hole Count
Totlength	decimal(14,3)	14,3*	Total Length - The total length in inches for all items produced or reclaimed in this Production record. This field will never include scrap.	*Lengths will be in decimal inch	
Footage	decimal(14,3)	14,3*	Footage - The total length in inches for all good, reclaimed, and/or scrap footage in this Production record.	*Lengths will be in decimal inch	

Eclipse Production Data Export Database Structure

Code_type	char(1)	1*	Code Type - Details the type of code (Downtime or Scrap) reported for this Production record.	*This field will only contain: D or S	D = Downtime Code S = Scrap Code
Code_val	smallint	3	Code Value - The actual numeric Scrap or Downtime Code selected by the Machine Operator.		
Code_desc	varchar(30)	30	Code Description - A textual description of the Downtime or Scrap Code reported by the Machine Operator as defined under either Maintenance\Delay Code Definitions or Maintenance\Scrap Code Definitions.		
Code_exmpt	character	1*	Code Exempt - Indicates of the Downtime Code or Scrap Code is exempt.	*This field will only contain: E, N, or empty string	E = Exempt N = Not Exempt empty string = No code reported for this record.
Duration	decimal(8,2)	8,2*	Duration - Time elapsed since last Duration reported.	*Times will be in minutes	
Machstatus	character	1*	Machine Status - The Run mode status of the machine at the time the record was reported.	*This field will only contain: H or R	H = Halted R = Running
Minutes	decimal(11,2)	11,2	Minutes - Date and time converted to minutes since January 1, 1980.		
Machdesc	varchar(30)	30	Machine Description - A textual description of the Machine from which the current Production record was generated as defined under Maintenance\Machine Definitions.		
Wrkgroup	varchar(2)	2	Machine Group - If the Machine reporting this Production Record belongs to a Machine Group as defined under Maintenance\Machine Groups, then it's associated group number appears in this field.		
Ordertype	character	1**	Order Type - Indicates whether cutlist items for this order were defined in terms of finished part lengths, or in terms of hole count.	*This field is optional, unless the user must transmit orders to machines that use XL Series controllers with the Hole Count software option, in which case it is required **This field will only contain: H or empty string	H = hole count programming empty string = standard length programming
Workorder	varchar(18)	18	Work Order - The Work Order number as imported or entered into Eclipse.		
Custname	varchar(30)	30	Customer Name - The Customer Name as imported or entered into Eclipse associated with the current Order Number.		
Part_num	varchar(30)	30	Part Number - The Part Number currently being produced at the time this Production record was created.		
Pattern	smallint	3	Pattern Number - Pattern Number used at controller for punched part.		
Heatnbr	varchar(20)	20	Heat Number - Heat Number of Coil currently loaded on the Machine as entered or imported to Eclipse.		
Invcoil	varchar(16)	30	Coil Number - The inventory Coil Number currently loaded on the Machine for this Production record.		
Coilmatl	varchar(20)	20*	Coil Material Code - The Material Code defined for the currently loaded Coil.		
Matlwidth	decimal(6,3)	6,3*	Material Width - The Material Width of the currently loaded Coil as defined under the Maintenance\Material Code Definitions table.		
Lb_ft	decimal(7,3)	7,3*	Pounds Per Foot - The weight per length unit for the currently loaded coil if the data is available, or the average weight per length unit for the current material type if the data is available in the Material Definitions table.	*Weights will b in pounds.	
Cost_lb	decimal(7,2)	7,2	Cost Per Pound - The cost per weight unit for the currently loaded coil if the data is available, or the average cost per weight unit for the current material type if the data is available in the Material Definitions table.		

Eclipse Production Data Export Database Structure

Code_resp	numeric	1*	Code Responsibility - General area of responsibility for code.	*This field will only contain: 0, 1, 2, or 3	0 = Not Specified 1 = Operational 2 = Equipment 3 = External
Runtime	decimal(8,2)	8,2*	Run Time - The amount of time the Machine has been in run for this Production record.	*Times will be in minutes	
Downtime	decimal(8,2)	8,2*	Down Time - The amount of time the Machine has been down for this Production record.	*Times will be in minutes	
Exemptime	decimal(8,2)	8,2*	Exempt Time - The amount of down time that was exempt for this Production record.	*Times will be in minutes	
Good	decimal(14,3)	14,3*	Good Length - The amount of Good length reported in this Production record - does not include reclaimed length.	*Lengths will be in decimal inch	
Scrap	decimal(14,3)	14,3*	Scrap Length - The amount of Scrap length reported in this Production record.	*Lengths will be in decimal inch	
Exmptscrap	decimal(14,3)	14,3*	Exempt Scrap Length - The amount of exempt scrap length reported in this Production record.	*Lengths will be in decimal inch	
Reclaimed	decimal(14,3)	14,3*	Reclaimed Length - The amount of Reclaimed length reported in this Production record.	*Lengths will be in decimal inch	
Actspeed	decimal(8,3)	8,3*	Actual Speed - The current Line Speed of the Machine at the time this Production record was reported. This is not a throughput value, but true Machine speed.	*Speeds will be in feet per minute	
Targspeed	decimal(8,3)	8,3*	Target Speed - The target Line Speed of the Machine as defined in Machine Definitions, superceded by Target FPM as defined in Base Efficiency Values, superceded by Target FPM as defined in Product Code Definitions\Length Related Data.	*Speeds will be in feet per minute	
Toolchg	tinyint	1*	Tool Change - Details whether a Tool Change occurred to produce the current Order.	*This field will only contain: 0 or 1	0 - No Tool Change occurred 1 - Tool Change occurred
Matlchg	tinyint	1*	Material Change - Details whether a Material Change occurred to produce the current Order.	*This field will only contain: 0 or 1	0 - No Material Change occurred 1 - Material Change occurred
Coilchg	tinyint	1*	Coil Change - Details whether a Coil Change occurred to produce the current Order.	*This field will only contain: 0 or 1	0 - No Coil Change occurred 1 - Coil Change occurred
Matldev	tinyint	1*	Material Deviation - The Material Code for the currently loaded Coil does not match the Material Code specified by the current Order.	*This field will only contain: 0 or 1	0 - No Material Deviation occurred 1 - Material Deviation occurred
Listid	int	10	Custom List ID - Custom List ID interface reported for this Production record.		
Listtext	varchar(40)	40	List Text - The specific text presented to the Machine Operator at time of List generation.		
Listvalid	varchar(100)	100	List Value - The value reported by the Machine Operator in response to the List Text.		
Startlngth	decimal(11,3)	11,3*	Starting Length - The starting length of a Coil verified from the ERP system's table.		
Oth_adjst	decimal(11,3)	11,3*	Other Adjustments - Any length adjustments to a Coil from offline processes.		
Holecount	smallint	4	Hole Count - If the XL series controller is in Hole Count mode, this field reports the current programmed Hole Count value for the Machine Controller.	*This field is required by customers who use XL Series Machine controllers with the "H" designator in the software model number	
Offset	decimal(8,3)	8,3**	Offset - Defines the distance (from the leading edge of a hole picked up by a photo-eye) where the Machine controller will fire the cutoff when operating in Hole Count mode.	*This field is required when using the "Holecount" field **Lengths will be in decimal inch	

Eclipse Production Data Export Database Structure

Bndlecd	varchar(15)	15	Bundle Code - Some ERP systems use a specific Bundle Code to dictate bundling rules for the operator. This field is simply passed along and displayed or printed where ever the user selects.		
Sk	varchar(50)	50	SKU - SKU is a code that typically contains data pertaining to both the finished part's profile and raw material properties. If the company uses a SKU number for parts, Eclipse will accept SKU and pass it back.		
Scrapqty	numeric	5	Scrap Quantity - When a Machine Operator uses Remake or Increase Quantity to replace scrapped parts, this field will indicate the number of good parts that were produced to replace scrapped parts.		
Exptmatlen	decimal(14,6)	14,6*	Expected Material Length - The total length of raw material consumed to create the finished part. For tile machines and spiral duct work machines, this field can be compared to the length field to determine the difference between material consumed for a finished part and finished part length.	*Lengths will be in decimal inch	
Shearkerf	decimal(14,6)	14,6*	Shear Kerf - The length of material scrapped during the shearing process.	*Lengths will be in decimal inch	
Bundleid	character	15	Bundle ID - Many ERP systems generate unique identifiers for each cutlist item, or bundle of cutlist items, within an order. Optionally, the XL/Eclipse system can generate a unique identifier.		

